


# Installation process of driving and printing software

## 1、Driver Installation


1. Open the printer and connect to your computer with USB
2. Open this toolkit and you can see TSC (driver ) and BT (software )



- 2、First install the driver, click on the driver, and start the installation. Select accept, select the installation location, click next, click finish. And Start importing.



3、Go on to the next step. Select other (such as parallel or serial) when how this printer connects, and then click next. In step 3, select TSC TTP-245, and then proceed to the next step. In step 4, proceed to the next step. Step 5 also choose the next step. Finally, click finish.




At this point, the installation of the driver is complete. The next step is the configuration of the driver.

## 2、Driver configuration

1、Find Devices and printers and click start configuration.

2、Step 2, after the "TSC TTP-245" selection, the right mouse button is set to the default printer, and select Printer Properties.

3、Step 3, in the Port option, select USB.. As a port, click apply at the bottom, and then click confirm. At this point, the configuration is over.



### 3、Install print software


1、Double-click the printing software to start installation.



2、Confirm




3、Wait



4、Next



5、Select accept and move on to the next step




## 6、Select the installation path




## 7、Start installation



## 8、Wait




9、Click Finish




10、Start to use







11、Choose according to your needs, if by default, please keep on the next step. When printing paper properties are configured, fill in different paper properties according to the machine. Then proceed to the next step, and finally choose to confirm



12、Edit Interface



13、According to your needs, drag the tool in the tool box and start editing



14、Start printing



